



Assembly Instructions

1. **Open the carrying case and remove the Summit banner stand. The feet will snap into place automatically.**
2. **Remove the graphic panel(s) from the tube, unroll it and snap the aluminum hanger in place at the top of the mast.**
3. **Loosen the black spin-lock collars to extend the mast. Adjust the mast to the height of your graphic and then tighten the collars. Affix the black tab at the bottom of the graphic to one of the black pins on the base. Adjust the mast to insure that the graphic is now taut.**
4. **To raise the bottom of the graphic off the ground, position the sliding ring to the desired height and tighten in place.**
5. **Attach the lamp to the top of the mast by sliding the fixture onto the t-bar. Plug into power source.**

Your display is ready for business!

6. **To repack: Loosen the spin-lock collar(s) and remove graphic. Roll the graphic panel(s) with the graphic side out and place in carrying case. Slide mast down fully, tighten collar(s), collapse feet, place banner stand in carrying case.**

